

# LIGHTING PRODUCTS

# FIRE RESEARCH CORPORATION

26 Southern Blvd., Nesconset, NY 11767 TEL 631.724.8888 FAX 631.360.9727 TOLL FREE 1.800.645.0074



CLA100-A14



# **MODEL CLA100 Series**

## **SAFETY SUMMARY**

FRC lighting products are engineered and manufactured with safety in mind. It is critical that FRC lights are installed, maintained, and operated correctly. Read and understand all instructions before installing, performing maintenance, or operating.

All components, equipment, and installation procedures shall conform to NFPA 1901, Standard for Automotive Fire Apparatus and NFPA 70 National Electrical Code.

## **General Safety Precautions**

Do not stare directly at LEDs when power is on.

Ensure power is off prior to connecting or disconnecting wires/cables and plugs to a power source or performing maintenance.

Disconnect ground connection from battery marked '-' to avoid accidental short circuits before attempting to connect electrical wires.

#### **Installation Safety Precautions**

Connect the LED light to a 12 or 24 volt DC power source.


Ensure an appropriate sized circuit protection device is installed (circuit breaker or fuse). See Power Requirements chart below.

#### INSTALLATION INSTRUCTIONS

Before mounting, check the identification label on the light for specific voltage and current requirements. Check that the length of the wiring is correct. Ensure the CLA100 is mounted so that the lens is focusing the light in the desired direction.

Note: Before drilling holes place the light in position to check for fit. Ensure that the light clears all obstructions.

- 1. To drill the appropriate mounting hole(s), measure and mark the two mounting hole locations. Refer to the chart and drawings on page 2 for the mounting hole dimensions of the light being installed.
- 2. Attach the mounting brackets using the provided hardware, as indicated in the drawing below.
- 3. Mount the LED light by using provided hardware to fasten it to your apparatus. If the M6 fasteners (A) are not long enough to attach to your apparatus, it is recommended to use longer fasteners, such as longer length M6 or 1/4 inch (not supplied) with the appropriate nut.



- A. M6 x 20mm Socket Cap Screw
- B. M6 Flat Washer
- C. M6 Lock Washer
- D. M6 x 14mm Socket Cap Screw
- E. Mounting Bracket
- F. Gasket
- G. M6 Nylon Lock Nut

#### WIRING

		Model Number			
Label Name	Wire Color	CLA100-A14	CLA100-A49, CLA100-A62 & CLA100-A68		
Negative	Black	х	x		
Narrow Flood	Green		x		
Marker	Yellow		x		
Low Beam	Red	х	X		

NOTE: All models have 4 wires, except for CLA100-A14. CLA100-A14 has 2 wires.

NOTE: Lamphead is supplied with a 32" long cable (3/8" OD) with 14 AWG wires.

NOTE: See Power Requirements on page 2.


# **Install Crest Light CLA100 Series**

 = Marker lights (amber LED color) all other leds to be white


= Low Beam

= Narrow Flood


<u>Key</u>




#### CLA100-A49



#### CLA100-A62



#### CLA100-A68



Power Requirements									
Model	Supply Voltage (VDC)	Marker (Amber)	Low Beam	Narrow Flood	Total Power (Watts)	Output (Lumens)			
CLA100-A14	12/24	_	50	_	50	2,600			
CLA100-A49	12/24	10	85	70	165	12,500			
CLA100-A62	12/24	10	110	90	210	16,100			
CLA100-A68	12/24	10	134	90	234	17,800			

1635.1

70 3/4

1797.1

76.2

3

76.2

46.1

1 13/16

46.1

84.1

3 5/16

84.1

### **MAINTENANCE**

Use a clean soft cloth, mild soap, and water to clean the lens.

**CLA100-A68** 

MM

**INCH** 

MM

1657.4

71 5/8

1819.4

**NOTE:** FRC LED lampheads use Lexan lenses and cleaning with abrasive materials, solvents, or most chemical cleaners can cause lens surface degradation and reduced performance of the light. **Some chemicals will cause the lens to become brittle and prone to cracking.** 

**NOTE:** Do not use Loctite on any screws near the lamphead lens. FRC LED lampheads use Lexan lenses that can become brittle and prone to cracking when exposed to Loctite compounds.